

Bum Wrap Drum Co. – Drum Wrap Sizing Chart

Drum wrap measurement guide with 1.5" seam overlap and trimming allowance.

Formula: **Circumference = Diameter × 3.14**

Wrap Length = Circumference + **1.5" overlap**

Wrap Depth = Shell Depth + **1/2" extra material on EACH side** (1" total) for trimming and filing.

Drum Diameter (inches)	Shell Circumference	Wrap Length (Circumference + 1.5")
6	18.84	20.34
8	25.12	26.62
10	31.4	32.9
12	37.68	39.18
13	40.82	42.32
14	43.96	45.46
15	47.1	48.6
16	50.24	51.74
18	56.52	58.02
20	62.8	64.3
22	69.08	70.58
24	75.36	76.86
26	81.64	83.14

Installation Notes:

- Wrap length includes a 1.5" seam overlap.
- Add 1/2" of extra wrap depth on BOTH sides of the shell (1" total).
- Always dry fit wrap before applying adhesive.
- Recommended adhesive: 3M 30-NF Fastbond Contact Adhesive.

Bum Wrap Drum Co. – www.bumwrapdrumco.com